



BOURGAULT

X30

Monitor/Controller

INGENUITY.

SIMPLICITY.

DURABILITY.

 **TOPCON**
Precision Agriculture

www.bourgault.com



X30 System Components





X30 Monitor

- Monitor is 12.1 inches
- LINUX operating system – not windows
- Can-based communication. No serial ports
- New part number 3132-10





LED Light Bar

Light Sensor





Battery Status LED

Supply Status LED








The following offers a general guide to the meaning of battery status LED colors.


-  Battery fully charged
-  Battery partly charged
-  Battery flat
-  Charging (flashing)

The following offers a general guide to the meaning of power supply status LED colors.

-  Good supply
-  Low supply
-  Very low supply or off



Before removing the USB, always disconnect first by touching the **USB Eject** icon on the base of the console. A message will display that it is safe to remove the USB.



Use the **Topcon Logo** for screen shots or navigate through your made global home screens.



Brightness Control adjusts the brightness of the display. Use plus or minus to adjust display.



Day/Night mode changes the brightness of the display. Settings are Day, Night and Auto. Auto light mode will set the mode automatically depending on light conditions



Bridge ECU

- Added into the cab of tractor
- Replaces SRC interface box used for the X20
- Translates RS485 from on tank ECU to CAN for X30
- ISOBUS Capable (can be used with a ISO terminal future)
- Bourgault Part Number 3132-13
- Topcon number AGA4634
- Both the ISO bridge adapter cable and the main power cable hooks into this
- Upgradeable though the USB port





X30 Main Harness

- Connects X30 to power, bridge ECU, GPS Signal, remote steer engage (if equipped with Topcon)
- Bourgault Part Number 3132-12-01
- Topcon Harness AGA5072

Hooks to main battery cable

CAN 1 to the ISO bridge through the Can harness

ENGAGE wire Hooks to the ISO bridge adapter cable AGA4885


Switched power connects to terminator Harness AGA4678

COM 2 hooks to outside receiver for GPS

COM 1 Hooks to GPS adapter cable AGA4219 for connection to outside receiver for GPS

NOTE; GPS can be brought in though either COM 1 or Com 2

Also the can 2, remote mapping and radar plugs are not used.




Power and communication plugs that hook to the back of the X30



Can harness

- Connects bridge ECU to Topcon monitor harness
- Bourgault Part number 3132-09-01
- Harness Number AGA5251



Hooks to the ISO Bridge

Connects to the terminator harness
AGA4678


Connects to the can1 plug on the
main power Harness AGA5072



Terminator harness

- Connects Can harness to Topcon monitor harness
- Bourgault Part number 3132-09-02
- Harness Number AGA4678

Terminator part number
Bourgault 3132-09-03
Topcon AGK159



Connects to switched power plug
on the monitor harness AGA5072

Connects to the iosbus plug on the
Can harness AGA5251




Bridge ECU adapter harness

- Connects bridge ECU to Topcon tractor harness
- Connects Switchbox and Switch power to the ISO bridge.
- Bourgault Part number 3132-06
- Harness Number AGA4885

X30 engage wire

Hooks to the engage wire on the main power
Harness AGA5072



Hooks to cabin switch box

Hooks to the tractor harness

Hooks to the ISO Bridge



X30 power Harness

- Connects X30 main harness to the battery
- Included in 3132-04 package
- Highly recommended to hook direct to the battery
- Bourgault Part Number 3132-04-03
- Topcon Harness AGA4073




Hooks to the main X30 power harness



GPS Adapter Harness


- Connects receivers to Main X30 harness on Com 1
- Includes gender changer/ Null Modem
- Bourgault Part number 3132-04-04
- Topcon Harness AGA4219






Multi clutch switch box

- Master switch
- Six tank switches
- Bourgault Part number 3132-01



Hooks to the ISO bridge adapter harness
AGA4885



110V power converter


- For use at home outside of the tractor
- Bourgault Part number 3132-07





User


1. Language
2. Time/Date
3. Units
4. Light bar (used for steering)
5. Environment
6. Map
7. Access





Language


- Just touch the each bar to
Can change the language
Decimal point format





Time/Date


- Just touch each bar to
Set the Date format: the way it shows
Set the Time format: 12hrs or 24hrs
Set the current time: this will set itself when
you hook to GPS signal





Units

- Units: **imperial (US)**
- Latitude: **DMS**
- Pressure: **PSI**
- Area: **acre**
- Dry Product: **bushels**
- Dry Density: **pounds per cubic foot**
- Liquid units: **Gallons**
- Application Rate: **fixed rate**





Environment Setup

-Audio Volume %

The volume of the audio and button clicks.

- Button Clicks on/off

Clicking sound every time you touch a button.

-Alarm Audio on/off

Whether or not you want the audio part of the alarm

-Touchscreen Calibration

If the screen is out of calibration. Restart required


-Sensitivity of touchscreen

Change the sensitivity. Restart required

-Multi-function Region Mode this is talking about the Topcon symbol on the front of the monitor. When screen shots is selected it allows you to take a picture of the screen your on. When global home screen is selected it allows you to build home screens and you can toggle through with touching the Topcon symbol.

-System transfer Not used


-Steering status used for Topcon steering



The logo for Bourgaault, featuring the word "BOURGAULT" in a stylized, bold, white font with a red underline, set against a black oval background with a silver border.

Maps


- **Point of focus:** Allows you to set the point of focus to either the vehicle or the implement
- **Map Planning:** allows you to pan through the map with your finger and drag it to where ever you like. So you can see parts of the map that aren't on the screen
- **Map focus auto shift:** if this is enabled it will automatically refit the map in the guidance screen when you have any mini views out.
- **Highlight loaded coverage:** when enabled, as product is being applied covered area will be in green and the previously covered will be yellow.
- **Visual reference line length:** allows you to Set a visual reference line length





Access Level

- Allows for access to some feature (like diagnostics) not accessible at the Operator level
- **Provision USB for upgrade**
This allows you to unlock the software on a thumb drive when an update is required.



BOURGAULT

X30

Monitor/Controller

Steering: DISENGAGED

Select Feature



VIRTUAL TERMINAL
Disabled



REMOTE ASSISTANCE
Disabled



FILE SERVER
Enabled



CAMERAS
Disabled



PER-POINT DATA LOGGING
Disabled



WIRELESS NETWORK
Disabled



Console



Guidance



Implement



Features



GPS



Serial Ports



Alarms



Flag Points



Area Counters



Quick Start



User



System



Vehicle



Implement




Product



Guidance


- **Guidance** (this is always enabled)
- **Auto Steer** (used with Topcon Steer)
- **Reverse Detection** (Topcon Steer)
- **Controlled Traffic** (Topcon Steer)
- **Job Helper Mode** adds a pop up menu to the guidance screen for navigation ease. You can have either Job Assist or Quick Start.





Implements

- Auto Sectional Control: ON** if you want the guidance to turn the clutches on and off. Or if you're using sectional control NH3 or Liquid.
- Variable Rate Control** if using a VR map
- Task Data (not used)
- Agjunction (not used)





GPS Receiver

- **GPS Receiver** use other for non Topcon
- **Baud Rate** set to the rate that your receiver is outputting.



BOURGAULT


X30


Monitor/Controller


Not Used


Steering: DISENGAGED







GPS Output Settings


 **GPS OUTPUT**
Disabled


 **BAUD RATE**
19200


 **MAXIMUM RATE**
5 Hz


 **OUTPUT PRECISION**
High Precision


Sentence		State
GGA		Disabled
GSV		Disabled
VTG		Disabled
GSA		Disabled
ZDA		Disabled
RMC		Disabled


 Receiver


 Output


 Radar


 Features


 GPS


 Serial Ports


 Alarms


 Flag Points


 Area Counters


 Quick Start

 User

 System

 Vehicle

 Implement

 Product



Not Used






Serial Port

Receiver Com this needs to be set to match the way that you have brought in the signal into the X30


Output Com have this set to something different then what the receiver Com is





Alarms

- Alarms that deal with the console, GPS or Steering. All can be disabled



BOURGAULT



Seeder Alarms


- All the alarms for the seeder, can be turned on or off individually





Flag Points

- With all the flag points you can change the description or name of the point





Area Counters


-**Area counters** (on/off)

-**Reset area** (never, auto, and Prompt)

Never: area will never reset unless the operator does it

Auto: it will automatically reset every time they start a new job.

Prompt: it will prompt you every time that you start a new job



BOURGAULT

X30

Monitor/Controller

Steering: DISENGAGED

Quick Start Settings

Options

✗	Export Job Report for previous job
✓	Change Field
✗	Record Boundary
✓	Change Job
✗	Set Headland Mode
✗	Set Guideline Mode
✗	Change Guideline
✗	Auto-hide on Success

Features

GPS

Serial Ports

Alarms

Flag Points

Area Counters

Quick Start

User

System

Vehicle

Implement

Product



Select Vehicle


- You can change between different vehicles that you have created
- You can load a vehicle from another monitor through a USB
- If you change the vehicle in this page it will restart the monitor






New Vehicle

- This is where you can go in and create a new vehicle by selecting the proper manufacture.
- Then it will ask you to pick the model of the unit if its not there pick a model that is close to right one.



Vehicle Geometry


- After the unit is picked you will have to come in and adjust the measurements specific to each vehicle
- Ensure distance from receiver to rear axle, rear axle to the hitch and the receiver to the center of the machine are accurate as this will affect ASC/Mapping
- The rest are primarily for steering application
- Some steer systems require odd dimensions to steer (AES25) Topcon





Select Implement

- This is where you will pick the machine that you are operating
- Every time you create a new profile it will appear here






Factory Profile

-Follow though a few steps to configure your monitor to the machine you are working with.

-Start by picking the series of tank that you have. Touch and highlight the proper one then press the green arrow.


-Setting up a profile for both 6000/7000 a basically the same as you go though





Factory Profile

Select the model for tank by highlighting it then press the green arrow to move on.






Factory Profile

This is where you pick how your machine is configured. How many meters and weather or not you have sectional NH3/LIQ. Find the one that fits your tank and highlight it and press the green check mark.

NOTE: you will see in a four tank configuration that it has a T3 or a T5.

T3 - means that the fourth meter is on tank three.


T5 - means that the fourth meter is on the saddle tank.





Factory Profile


- Pick Bourgault then go ahead and press the green check mark.
- At this point it will tell you that the X30 will need to perform a reboot. Just touch on the green check mark to move on.





Factory Profile


- Highlight the machine that you will be using. Then press the green check mark to proceed.
- If the machine that you are using is not listed you will have to pick one. After you have to go into the geometry and change the dimensions to fit the machine you have.





Factory Profile


- Find the machine that fits then highlight it and hit the green check mark to move on





Factory Profile


- Pic the one that matches the your machine, highlight and pick the green check mark to move on.





Factory Profile

- On this screen it allows you to the name the unit simply by touching on the box with the name in it.
- Then a key pad will come up for you to type the name.
- When finished then touch the green check mark to move on
- So when its on the select tab you will be able to recognized it.





ECU Setup

- This page shows what ECU and drive each tank is working through it will also let you know what firmware versions they are running when connected to the tank

ECU Setup (ISO Bridge) - 7700 NH3 (Seeder)

REFRESH ECU SETTINGS
Click to retrieve current settings from ECU

Tank	Name	Type	ECU Name	Firmware Version
1	Tank 1	Granular	MDECU - Drive 1	N/A
2	Tank 2	Granular	MDECU - Drive 2	N/A
3	Tank 3	Granular	MDECU - Drive 3	N/A
4	Tank 4	Granular	MDECU - Drive 4	N/A
5	Tank 5	Granular	SECU - Drive 1	N/A
6	Tank 6	NH3	SECU - Drive 2	N/A

Select New **ECU** Geometry Section Control Switch Box Seeder

User System Vehicle **Implement** Product



Implement Geometry

These values should be set into the monitor from the factory but should be checked to make sure.

A- enter the width of the implement. If using Sectional control the value will be entered in the section setup screen


B- overlap (not used)

C- depth (not used)

D- from the pin to the front row of openers or MRB

E- from the main pin to the center of the caster hub or the High Flotation hub

H- from the front row of openers to the back row of openers.



The BOURGAULT logo is displayed in a stylized, italicized font within a black oval frame with a silver border.The X30 Monitor/Controller logo features the text "X30" in a large, bold, sans-serif font, with "Monitor/Controller" in a smaller font below it, all enclosed in a silver and black border.

Section Setup

- Enter # of section and the width of each for the Multi-section boom
- It can be set all the same or individually
- If using multi-section the total width will auto Populate into the geometry screen
- Nozzles numbers only come into effect with Liquid

Section Setup - 7700 NH3

1  SECTIONS 8

Section	Width (787.2")	Nozzles
All	-----	----
1	98.40"	5
2	98.40"	6
3	98.40"	6
4	98.40"	6
5	98.40"	6
6	98.40"	6
7	98.40"	6
8	98.40"	5

The bottom of the screen features a navigation menu with icons and labels: Select, New, ECU, Geometry, **Section Control** (circled in red), Switch Box, Seeder, User, System, Vehicle, **Implement** (circled in red), and Product. A red line connects the 'Section Control' icon in the menu to the 'Section Control' icon in the main display area.



BOURGAULT



Sections Timing


- Look ahead times for the individual section valves
- For NH3/ LQd would typically be the same as the tank on/off times
- This will come more into affect with granular





Section Switch


- Enable a virtual switchbox so that you can manually control sections on screen
- This virtual switchbox will show up on the guidance Page
- Only works if your using sectional control





Granular Sections


- Related to section valve state monitoring, not applicable without granular section control





Switch Box

- Master Switch –
- **virtual** - allows you to use the touchscreen
- cabin switchbox** – to use the external switchbox
- Implement** – to use the machine to turn the clutch on
- On position **UP**
- Cabin switchbox
- **6 channel** if your going to use the external box it must be put on this setting
- **disabled** if your not going to use the external box
- Calibration **enabled**



General Tank Setup

- Accessed by selecting the tab on the top of the Individual tank's
- Name (Bin/Tank)
- Product as name (enable/disable)
 - * Sequencing on time (0-10 sec)
 - * Sequencing off time (0-10 sec)
 - ** Preload time (0-15 sec)
- Fan to start- ensures a min speed before the metering can be activated. Can prevent plugging/ meter damage. Should be set to around 1000
- Master clutch used with 6000 AS




- Sequence Time's – On time based on measured time from when the meter starts to when product is at outermost openers of machine. Typically 3-4 Seconds. Off Time is based on measured time from when the meter stops to when the products stops flowing at the outer most openers. Typically 3-4 sec. Can add some time to ON and remove some time from OFF for safety factor to ensure there are no misses.

** Preload Time – When starting a seeding pass from a stop it allows for product to be at the openers when before moving. Also the time the meters will run when the **PRIME** button on-frame switchbox is pushed. Good for priming for calibrations or if wanting to check plugged runs.



Tank Setup

- **Name** you can name how it is seen on the seed rate controller screen.
- **Capacity** the amount of product that will fit in the tank. It can be altered.
- **Status** if not using one of the tanks you can come in and disable them.
- Accessed by selecting one of the numbered tabs on the left hand side. Or the arrow to move the tanks up or down




HINT: if tank is not being used disable it otherwise system won't allow you to start applying.
All enabled tanks need a cal factor even if they are switched off



Tank Grouping

Groupings are pre-set from the factory use the arrows on the right hand side to scroll through them


- Tank volumes update automatically





Drive Setup

- Toggle between the tanks with the tabs on the left Hand side
 - Drive type – **proportional for 7000 AS**
 - linear for 6000 AS
 - Pulses/ Revolution – **32 for 7000 AS**
 - 16 for 6000 AS
 - Minimum RPM set at **10**
 - Maximum RPM set at **1000**
 - Metering Auger pick corresponding augers to each tank
- Accessed by selecting one of the numbered tabs on the left hand side. Or the arrow to move the tanks up or down



BOURGAULT


X30

Monitor/Controller

Controller Settings

- Minimum PWM (**15%**)
- Maximum PWM (**95%**)
- Controller Response (**medium fast**)

- Accessed by selecting one of the numbered tabs on the left hand side. Or the arrow to move the tanks up or down





Tank Setup

- Product Name enabled/disabled
- Sequence On/Off

Times work similar basis as granular on/off, based on time for product to reach openers after switched on/off, usually a bit faster then granular



The logo for Bourgaault, featuring the name in a stylized, italicized font inside a dark oval with a metallic border.The logo for the X30 Monitor/Controller, featuring the text "X30" in a large, bold font above "Monitor/Controller" in a smaller font, all within a shield-like border.

Tank Setup


- Name - can name each tank/bin
- Capacity – can be changed to match your tank
- Status (enable/disable) if your not using one for a field
- Section Control (NH3 if you are, full width if single boom)
- Pump Speed (not used)



Flow Setup

- Calibration Factor – Can be set here or on the SRC screen
- Flow Confirmation (not used)






Control Valve Setup

- Similar to the options of the X20
- Pick between regulator or proportional



Pressure Sensor


Not Used





Fan Setup

- Toggle through the different fans using the tabs On the left hand side
- Fan speed – disable if not using one of fans
- Pulses (1)





Pump Speed

Not Used



BOURGAULT

X30

Monitor/Controller

Blocked Head Monitor

- Block head monitor (**enabled/disabled**)
- Sensor Type (**dickey - john**)
- Head monitoring **Single/double shoot**
- Number of sensors **1 – 20 max**
- On the right hand you can name individual runs

Steering: DISENGAGED

Blocked Head Monitor Setup - 7950 4TANK-MTRG-T3_3320-40 10SPCG

Seed Heads	Fertiliser Heads
---	---
SEED1 OLV	FERT1 OLV
SEED2 ILW	FERT2 ILW
SEED3 LMF	FERT3 LMF
SEED4 RMF	FERT4 RMF
SEED5 IRW	FERT5 IRW
SEED6 ORW	FERT6 ORW

Blocked Head Monitor Setup Options:

- BLOCKED HEAD MONITOR: Enabled
- BLOCKED HEAD SENSOR TYPE: DICKEY-john
- HEAD MONITORING: Double Shoot
- ENABLED HEAD SYSTEMS: Seed and Fertiliser
- NUMBER OF DISTRIBUTION HEADS: 12

Detect and Assign Sensors

Blocked Head Monitor (circled in red)

General Input

Monitoring (circled in red)

Speed Source

Seeder (circled in red)

Granular

Fans

ECU

Geometry


Switch Box

User **System** **Vehicle** **Implement** **Product**



General input setup


Not Used





Speed setup

- **Speed source** GPS
- **Fallback Type** manual speed
- **Wheel Factor** this is used when you switch the speed source to wheel. It will be set from the factory.




NOTE: GPS speed should be used at all times. Wheel speed is not consistent enough because of the amount of tire deflection. The rolling radius of the tires on the bigger machines can be changed up to 20% from full to empty



Product Setup


- You will need to come in and enter the products that will be used with this air seeder
- You are able to add new products at anytime.
- The way of entering new products is the same whether its liquid, granular or NH3.
- Touch on the New Product tab to start to enter a new product





New Product


- Highlight on Bourgault then touch the yellow arrow to move on to the next screens.





New Product


- Scroll through the list to find the product that you are wanting then highlight it and press the yellow arrow.
- If the product is not in this list find one that would be close in density. We can rename the product and change the density in the coming slides.






New Product


- Now you can rename the product to what ever you like. Just touch on the product name then it will bring up a keyboard so it can be named. When finished touch on the yellow arrow to move on.





New Product

- This is the final step, just touch on the green check mark to complete.





New Product

Density - Now you can go in and enter an known density if needed.

Rate Increments – the amount that the rate will change every time you touch the up or down arrow on the SRC screen.

Rate preset 1 – set the rate that you want to be using this product at.

Rate preset 2 – set a secondary rate you might want to use.

Once this is set every time you bring this product into one of your tanks these figures will auto populate in to the screen

