



## **Bourgault Drills, Airseeders and Cultivators**

### **Tech tips**

1. Re torque wheel bolts annually unless it is a new unit then follow the procedure on the next page.
2. Check all monitor harness connections before going to the field.
3. Check all power connections in the tractor annually.
4. Check monitor calibration as outlined in the operators manual.
5. Grease as outlined in operators manual.
6. Check tire air pressures annually.
7. Check wheel bearings annually.
8. Check hydraulic cylinders for leak down annually.
9. Check all product lines for wear and pinch points annually.
10. Check bander disk hub bearings for play annually.
11. Check shank bushings and pins annually.
12. Check tank lids for leaks annually.
13. Do a sensor learn before seeding.
14. Re check level of machine annually.
15. Clean out tanks and augers at the end of each season of use.

### **Torque procedure for a new unit**

1. Re torque wheel bolts after first hour of use or after 30 miles of road travel.
2. Re torque wheel bolts a second time after the first days use or after 100 miles of road travel.
3. Re torque the wheel bolts every 50 hours till they no longer come loose.

\*\* The painted surfaces tend to become loose as the paint turns to powder, re torquing will help prevent serious damage and or injury.