

Bourgault Air Seeder Monitors

82000 Monitors



82000 Monitor

Part # **AS12782**

- Used on select 115, 2115, 2155 air seeders
 - May be confused with the 101 monitor
- Displays* fan RPM / low bin alarms

132 & 101 Monitors



132 Monitor

Part # **AS12754**

- Available for 2130, 2135, 2155, 3165 & 3195 air seeders
- Displays* acres / ground speed / calibration

101 Monitor

Part # **AS12751**

- Available for 2115, 2115sp, 2130, 2135, 2155, 2195, 3165 & 3195 air seeders
- Displays* fan RPM / shaft stop alarm / low bin alarm

198 Monitor



198 Monitor

Part # **3120-41-01**

- Available for 2130, 2135, 2155 & 3165 air seeders
- *Displays* acres / calibration

70000 Monitor



- 70000 Monitor Part # **AS12781**
- Used on select 180, 155, 135 air seeders

149 Monitor



- 149 Monitor Part # **3120-50-02**
- Available for 2135, 3165, 3170, 3195 & 3225 air seeders

149 Module



- 149 Module Part # **3120-50-01**

May be used in conjunction with the 149 Monitor

Typically located under fifth wheel plate

277 Monitor



491 Monitor

Part # **3130-20** (v2.02)

Part # **3130-21** (High Power)

- Available for 3170, 3200, 3225, 4000 Series & 5000 Series air seeders. The high power version is also available on 6000 Series Air Seeders.
- The monitors can be differentiated between by noting the designation of “HP -High Power” on the front of the monitor.
- The high power monitors are required for units with full run optical blockage sensors.

491 Monitor



ZYNX / Bourgault SRC System Part # **3131-00**

- Available for 6000 Series & select 5000 Series air seeders.
- The ZYNX console is a Windows based computer system contained within an ABS housing.
- The console has a 6.4" VGA touch screen display and a stylus pen is included for making screen selections.
- COM ports on the back of the console are used for harness connections.
- The console is supplied with the Bourgault SRC and ZYNX Guidance programs installed. Optional software can be added for other applications.

277 Module

Part # **3120-65-12**

- Available for 2130, 2135, 2155, 3170, 3195, 3200, 3225, 4000 Series & 5000 Series air seeders
- Uses “Mux Bus” wiring system
 - White = Power (12v)
 - Black = Ground
 - Green = Data



- ZYNX Monitor / Control System requires specific sensors and harnesses, including an ECU module located on the air seeder frame.

